



DO **NOT** APPLY IF THE SURFACE TEMP IS LESS THAN 15 DEGREES C. USE A HAIR DRIER TO WARM THE AREA BEFORE APPLICATION IF UNSURE.



Step 1

Clean the area thoroughly with detergent and water (e.g. Fairy Liquid). Do not use Windolene or similar products because it may leave a residue behind that will prevent the sticker from adhering well. The area must be DRY!



Step 2

Prepare the sticker for application by firmly rubbing a squeegee or credit card across the clear transfer tape. This removes any air bubbles that may have formed and makes the sticker cling to the transfer tape.



Step 3

Peel the white paper backing off the sticker. If the sticker clings to the backing, slowly replace the paper backing and repeat Step 2.



Step 4

Slowly lower the sticker onto the surface and rub it in place firmly with a squeegee or credit card.



Step 5

Slowly peel the clear transfer tape off at an angle. Be careful not to pull the sticker off the surface. If sticker pulls away from the surface, carefully replace the application tape and repeat Step 4.



As you will see from the picture you should be left with 3 parts, the sticker applied to the surface, the application tape and the backing paper. These can be discarded. If you are not left with the two discardable pieces, re-read the above steps.

*Use a pin to poke any air bubbles in the centre and push the air out through the hole.

*For best results do not apply a sticker in extreme hot or cold temperatures. .

In the first few weeks after applying your decals please only lightly wash them, DO NOT PRESSURE WASH THEM.

To Remove Stickers: Heat the sticker with a hair dryer and peel the vinyl away from the surface. If there is any adhesive still on the window or body work, a little t-cut will remove this then glass or bodywork polish.

If you have any problems, please contact us, we are here to help!



Ways to contact us:
david@croftdecals.co.uk
07449 370 701